

Selector 1



16 MHz



1 MHz




500 kHz



250 kHz


Selector 2




125 kHz



62,5 kHz




31,25 kHz



15,625 kHz

Selector 3




3,9062 kHz



1,9531 kHz



976,56251 Hz



No se usa