



PITbUtils Specification

*Author: Per Larsson
pela@opencores.org*

Rev. 0.3
January 05, 2014

This page has been intentionally left blank.

Revision History

Rev	Date	Author	Description
.			
0.1	9/2/2013	Per Larsson	First draft
0.2	11/10/2013	Per Larsson	Added sections Acknowledgements and Language. Added reference section on waitsig(). Updated reference section on print() and pltbutils_clkgen.
0.3	1/5/2013	Per Larsson	Added sections User Configuration, Configuring Simulation Halt, Configuring Messages for Integration Environments. In reference section added starttest, endtest, removed testname. Updated figures and feature bullets.

1

Introduction

Overview

PITbUtils makes it easy to create automatic, self-checking simulation testbenches, and to locate bugs during a simulation. It is a collection of functions, procedures and testbench components that simplifies creation of stimuli and checking results of a device under test.

Features:

- Simulation status printed in transcript windows as well as in waveform window (error count, checks count, number and name of current test, etc).
- Check procedures which output meaningful information when a check fails.
- Clear SUCCESS/FAIL message at end of simulation.
- Easy to locate point in time of bugs, by studying increments of the error counter in the waveform window.
- User-defined information messages in the waveformwindow about what is currently going on.
- Transcript outputs prepared for parsing by scripts, e.g. in regression tests.
- Configurable status messages for use in continous integration environments, e.g. TeamCity.
- Reduces amount of code in tests, which makes them faster to write and easier to read.

It is intended that PITbUtils will constantly expand by adding more and more functions, procedures and testbench components. Comments, feedback and suggestions are welcome to pela@opencores.org .

The project page on the web is <http://opencores.org/project.pltbutils> .

Acknowledgements

PITbUtils contains the file `txt_util.vhd` by Stefan Doll and James F. Frenzel.


Language

Most parts of PITbUtils are compatible with VHDL-1993 to VHDL-2008.


Some parts are VHDL-2008 only, and some are VHDL-2002 to VHDL-2008.

If your tools (simulators, synthesizers, etc) are not compatible with VHDL-2008 or VHDL-2002, you can modify the code. There are comments in the files marking sections which are VHDL-2008 only, and VHDL-2002 to VHDL-2008 only. There are also commented out code which is compatible with earlier standards than VHDL-2008 and VHDL-2002. If you need to, comment out the VHDL-2008 (and/or VHDL-2002) code, and uncomment the VHDL-1993 (and/or VHDL-2002) code. After doing that, the code will still work, but you will lose some features or flexibility.

A quick look




During a simulation, the waveform window shows current test number, test name, user-defined info, accumulated number of checks and errors. When the error counter increments, a bug has been found in that point in time.



```
Transcript
File Edit View Window
# Loading std.textio(body)
# Loading ieee.std_logic_1164(body)
# Loading work.txt_util(body)
# Loading ieee.numeric_std(body)
# Loading work.pltbutils_type_pkg(body)
# Loading work.pltbutils_user_cfg_pkg(body)
# Loading work.pltbutils_func_pkg(body)
# Loading work.pltbutils_comp_pkg
# Loading work.tb_example(bhv)
# Loading work.dut_example(rtl)
# Loading work.pltbutils_clkgen(bhv)
# Loading work.tc_example(tc1)
#
# --- START OF SIMULATION ---
# Testcase: tc1
# 0 ps
#
# Test 1: Reset test (0 ps)
# Done with test 1: Reset test (15000 ps)
#
# Test 2: Simple sum test (15000 ps)
# Done with test 2: Simple sum test (35000 ps)
#
# Test 3: Simple carry in test (35000 ps)
# ** Error: Check 5; Sum; Actual=0x03 Expected=0x04 in test 3 Simple carry in test
# Time: 55 ns Iteration: 1 Instance: /tb_example/tc0
# Done with test 3: Simple carry in test (55000 ps)
#
# Test 4: Simple carry out test (55000 ps)
# Done with test 4: Simple carry out test (75000 ps)
#
# --- END OF SIMULATION ---
# Note: the results presented below are based on the PITbUtil's check() procedure calls.
# The design may contain more errors, for which there are no check() calls.
#       75 ns
#       4 Tests
#       8 Checks
#       1 Errors
# *** FAIL ***
V$IM(paused>]
```

The transcript window clearly shows points in time where the simulation starts, ends, and where errors are detected. The simulation stops with a clear SUCCESS/FAIL message, specifically formatted for parsing by scripts.



```

Transcript
File Edit View Window
Transcript
# -- Loading entity tc_example
# vsim -l ../log/tcl.log -GG_DISABLE_BUGS=1 tb_example
# Loading std.standard
# Loading std.textio(body)
# Loading ieee.std_logic_1164(body)
# Loading work.txt_util(body)
# Loading ieee.numeric_std(body)
# Loading work.pltbutils_type_pkg(body)
# Loading work.pltbutils_user_cfg_pkg(body)
# Loading work.pltbutils_func_pkg(body)
# Loading work.pltbutils_comp_pkg
# Loading work.tb_example(bhv)
# Loading work.dut_example(rtl)
# Loading work.pltbutils_clkgen(bhv)
# Loading work.tc_example(tcl)
#
# --- START OF SIMULATION ---
# Testcase: tcl
# 0 ps
#
# Test 1: Reset test (0 ps)
# Done with test 1: Reset test (15000 ps)
#
# Test 2: Simple sum test (15000 ps)
# Done with test 2: Simple sum test (35000 ps)
#
# Test 3: Simple carry in test (35000 ps)
# Done with test 3: Simple carry in test (55000 ps)
#
# Test 4: Simple carry out test (55000 ps)
# Done with test 4: Simple carry out test (75000 ps)
#
# --- END OF SIMULATION ---
# Note: the results presented below are based on the PITbUtil's check() procedure calls.
#       The design may contain more errors, for which there are no check() calls.
#       75 ns
#       4 Tests
#       8 Checks
#       0 Errors
# *** SUCCESS ***
VSIM(paused)>
    
```


The testcase code is compact and to the point, which results in less code to write, and makes the code easier to read, as in the following example.

```

library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
use work.pltbutils_func_pkg.all;

-- NOTE: The purpose of the following code is to demonstrate some of the
-- features in PlTbUtils, not to do a thorough verification.
architecture tcl of tc_example is
begin
    p_tcl : process
    begin
        startsim("tcl", pltbutils_sc);
        rst      <= '1';
        carry_in <= '0';
        x        <= (others => '0');
        y        <= (others => '0');

        starttest(1, "Reset test", pltbutils_sc);
        waitclks(2, clk, pltbutils_sc);
        check("Sum during reset",      sum,      0, pltbutils_sc);
        check("Carry out during reset", carry_out, '0', pltbutils_sc);
        rst      <= '0';
        endtest(pltbutils_sc);

        starttest(2, "Simple sum test", pltbutils_sc);
        carry_in <= '0';
        x <= std_logic_vector(to_unsigned(1, x'length));
        y <= std_logic_vector(to_unsigned(2, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",      sum,      3, pltbutils_sc);
        check("Carry out", carry_out, '0', pltbutils_sc);
        endtest(pltbutils_sc);

        starttest(3, "Simple carry in test", pltbutils_sc);
        print(G_DISABLE_BUGS=0, pltbutils_sc, "Bug here somewhere");
        carry_in <= '1';
        x <= std_logic_vector(to_unsigned(1, x'length));
        y <= std_logic_vector(to_unsigned(2, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",      sum,      4, pltbutils_sc);
        check("Carry out", carry_out, '0', pltbutils_sc);
        print(pltbutils_sc, "");
        endtest(pltbutils_sc);

        starttest(4, "Simple carry out test", pltbutils_sc);
        carry_in <= '0';
        x <= std_logic_vector(to_unsigned(2**G_WIDTH-1, x'length));
        y <= std_logic_vector(to_unsigned(1, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",      sum,      0, pltbutils_sc);
        check("Carry out", carry_out, '1', pltbutils_sc);
        endtest(pltbutils_sc);

        endsim(pltbutils_sc, true);
        wait;
    end process p_tcl;
end architecture tcl;

```

2

Tutorial

Basics

We will demonstrate how to use PITbUtils by showing an example. In this example, we have a DUT (Device Under Test / Design Under Test) with the following entity.

```
entity dut_example is
  generic (
    G_WIDTH      : integer := 8;
    G_DISABLE_BUGS : integer range 0 to 1 := 1
  );
  port (
    clk_i      : in  std_logic;
    rst_i      : in  std_logic;
    carry_i    : in  std_logic;
    x_i        : in  std_logic_vector(G_WIDTH-1 downto 0);
    y_i        : in  std_logic_vector(G_WIDTH-1 downto 0);
    sum_o      : out std_logic_vector(G_WIDTH-1 downto 0);
    carry_o    : out std_logic
  );
end entity dut_example;
```

As you can see, it has a clock- and a reset input port (clk_i and rst_i), three other input ports (x_i, y_i, and carry_i), and two output ports (sum_o and carry_o). There is also a generic, G_WIDTH, which sets the number of bits in x_i, y_i and sum_o. The second generic, G_DISABLE_BUGS, is very unusual in real designs, but it is useful in this example. We will reveal the purpose of this strange generic later, although some may already be able to guess what it is for.

To verify this DUT, we want the testbench to apply different stimuli to the input ports, and check the response of the output ports. The following code is an example of such a testbench. We will first show all of the code, and then explain parts of it.

```

library ieee;
use ieee.std_logic_1164.all;
use std.textio.all;
use work.txt_util.all;
use work.pltbutils_func_pkg.all;
use work.pltbutils_comp_pkg.all;

entity tb_example is
    generic (
        G_WIDTH           : integer := 8;
        G_CLK_PERIOD      : time := 10 ns;
        G_DISABLE_BUGS    : integer range 0 to 1 := 0
    );
end entity tb_example;

architecture bhv of tb_example is

    -- Simulation status- and control signals
    signal test_num       : integer;
    signal test_name      : string(pltbutils_sc.test_name'range);
    signal info           : string(pltbutils_sc.info'range);
    signal checks         : integer;
    signal errors         : integer;
    signal stop_sim      : std_logic;

    -- DUT stimuli and response signals
    signal clk            : std_logic;
    signal rst           : std_logic;
    signal carry_in      : std_logic;
    signal x              : std_logic_vector(G_WIDTH-1 downto 0);
    signal y              : std_logic_vector(G_WIDTH-1 downto 0);
    signal sum            : std_logic_vector(G_WIDTH-1 downto 0);
    signal carry_out     : std_logic;

begin

    -- Simulation status and control for viewing in waveform window
    test_num <= pltbutils_sc.test_num;
    test_name <= pltbutils_sc.test_name;
    info <= pltbutils_sc.info;
    checks <= pltbutils_sc.chk_cnt;
    errors <= pltbutils_sc.err_cnt;
    stop_sim <= pltbutils_sc.stop_sim;

    dut0 : entity work.dut_example
        generic map (
            G_WIDTH           => G_WIDTH,
            G_DISABLE_BUGS    => G_DISABLE_BUGS
        )
        port map (
            clk_i             => clk,
            rst_i             => rst,
            carry_i           => carry_in,
            x_i               => x,
            y_i               => y,
            sum_o             => sum,
            carry_o           => carry_out
        );

    clkgen0 : pltbutils_clkgen
        generic map(
            G_PERIOD         => G_CLK_PERIOD
        )
        port map(
            clk_o             => clk,
            stop_sim_i       => stop_sim
        );

```

```
tc0 : entity work.tc_example
  generic map (
    G_WIDTH          => G_WIDTH,
    G_DISABLE_BUGS  => G_DISABLE_BUGS
  )
  port map(
    clk              => clk,
    rst              => rst,
    carry_in         => carry_in,
    x                => x,
    y                => y,
    sum              => sum,
    carry_out        => carry_out
  );
end architecture bhv;
```

As the testbench example shows, the following packages are needed (in addition to the usual `std_logic_1164`, etc):

```
use std.textio.all;
use work.txt_util.all;
use work.pltbutils_func_pkg.all;
use work.pltbutils_comp_pkg.all;
```

`txt_util` contains useful text utilities, such as print procedures.

`pltbutils_func_pkg` contains functions and procedures for controlling stimuli and checking response.

`pltbutils_comp_pkg` contains component declarations for testbench components.

PITbUtils contain a number of hidden, global signals for controlling the simulation and keeping track of status. These signals are useful for viewing in the simulator's waveform window. To make them available for viewing, we declare a number of signals under the comment `Simulation status- and control signals`, and then make assignments to them under the `begin` statement.

The DUT is instansiated, as well as a clock generator component from PITbUtils. We also instansiate a testcase component (`tc_example`). This testcase component has an entity defined in one file, and the architecture defined in another file. This makes it possible to have several different testcases for the same testbench. Just compile the testcase architecture that you want to use for a specific simulation run.

The entity declaration for the testcase looks as follows.

```
library ieee;
use ieee.std_logic_1164.all;

entity tc_example is
  generic (
    G_WIDTH      : integer := 8;
    G_DISABLE_BUGS : integer range 0 to 1 := 0
  );
  port (
    clk          : in  std_logic;
    rst          : out std_logic;
    carry_in     : out std_logic;
    x            : out std_logic_vector(G_WIDTH-1 downto 0);
    y            : out std_logic_vector(G_WIDTH-1 downto 0);
    sum         : in  std_logic_vector(G_WIDTH-1 downto 0);
    carry_out    : in  std_logic
  );
end entity tc_example;
```

The ports of the testcase components are the same as for the DUT, but the mode (direction) of the ports are the opposite, so the testcase component can drive the inputs of the DUT, and detect the values of the output of the DUT. The only exception to this rule is the clock, which is an input, just as for the DUT.

One possible testcase architecture could look as the following code.

```

library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
use work.pltbutils_func_pkg.all;

-- NOTE: The purpose of the following code is to demonstrate some of the
-- features in PITbUtils, not to do a thorough verification.
architecture tcl of tc_example is
begin
    p_tcl : process
    begin
        startsim("tcl", pltbutils_sc);
        rst      <= '1';
        carry_in <= '0';
        x        <= (others => '0');
        y        <= (others => '0');

        starttest(1, "Reset test", pltbutils_sc);
        waitclks(2, clk, pltbutils_sc);
        check("Sum during reset",      sum,          0, pltbutils_sc);
        check("Carry out during reset", carry_out, '0', pltbutils_sc);
        rst      <= '0';
        endtest(pltbutils_sc);

        starttest(2, "Simple sum test", pltbutils_sc);
        carry_in <= '0';
        x <= std_logic_vector(to_unsigned(1, x'length));
        y <= std_logic_vector(to_unsigned(2, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",          sum,          3, pltbutils_sc);
        check("Carry out",    carry_out, '0', pltbutils_sc);
        endtest(pltbutils_sc);

        starttest(3, "Simple carry in test", pltbutils_sc);
        print(G_DISABLE_BUGS=0, pltbutils_sc, "Bug here somewhere");
        carry_in <= '1';
        x <= std_logic_vector(to_unsigned(1, x'length));
        y <= std_logic_vector(to_unsigned(2, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",          sum,          4, pltbutils_sc);
        check("Carry out",    carry_out, '0', pltbutils_sc);
        print(pltbutils_sc, "");
        endtest(pltbutils_sc);

        starttest(4, "Simple carry out test", pltbutils_sc);
        carry_in <= '0';
        x <= std_logic_vector(to_unsigned(2**G_WIDTH-1, x'length));
        y <= std_logic_vector(to_unsigned(1, x'length));
        waitclks(2, clk, pltbutils_sc);
        check("Sum",          sum,          0, pltbutils_sc);
        check("Carry out",    carry_out, '1', pltbutils_sc);
        endtest(pltbutils_sc);

        endsim(pltbutils_sc, true);
        wait;
    end process p_tcl;
end architecture tcl;

```

The testcase process starts with calling the procedure `startsim()`. This process clears all hidden, global control- and status signals, and outputs a message to the transcript and to the waveform window to inform that the simulation now starts. The first argument to `startsim` is the name of the testcase.

The last argument of `startsim()`, and to many other procedures in PITbUtils, is the name of the hidden, global status- and control signals. This argument must always look like this, with this name.

After initiating stimuli to the DUT, we call the procedure `starttest()`, for setting a name and a number for the following test. `starttest()` prints the test number and test name to the transcript and to the waveform window.

Then we need to wait until the DUT has reacted to the stimuli. We do this by calling the procedure `waitclks()`, which waits a specified number of cycles of the specified clock. The purpose is the

After this, we start checking the results, by examining the outputs from the DUT. To do this, we use the `check()` procedure. The first argument is a text string that specifies what we check, the second argument is the signal or variable that we want to examine, and the third is the expected value of the signal or variable. If the examined signal holds the expected value, nothing is printed. But if the value is incorrect, the string in the first argument is printed, together with the actual and expected values of the signal. The number and name of the test (as specified with `testname()`) is also printed. PITbUtils' check counter is incremented for every `check()` procedure call, and the error counter is incremented in case of error.

After the test, we call `endtest()`.


We make a number of different tests by calling `starttest()`, setting stimuli, waiting for the DUT to react with `waitclks()` or some other means, and checking the outputs with the `check()` procedure, and calling `endtest()`.

Finally, we call the `endsim()` procedure, which prints an end-of-simulation message to the transcript, and presents the results, including a SUCCESS or FAIL message.

The start-of-simulation message, end-of-simulation message, and SUCCESS/FAIL messages are unique, to make them easy to search for by scripts. This simplifies collection of simulation status for regression tests with a lot of different simulations.

Now test to run the simulation. Start ModelSim, and in the ModelSim Gui select the menu item File->Change directory... Navigate to the PITbUtils directory `sim/example_sim/run/` and click Ok. Then, in the transcript window, type `do run_tcl.do` .

The simulation will start, and the transcript from the simulation looks as follows.



```
Transcript
File Edit View Window
Transcript
# Loading std.textio(body)
# Loading ieee.std_logic_1164(body)
# Loading work.txt_util(body)
# Loading ieee.numeric_std(body)
# Loading work.pltbutils_type_pkg(body)
# Loading work.pltbutils_user_cfg_pkg(body)
# Loading work.pltbutils_func_pkg(body)
# Loading work.pltbutils_comp_pkg
# Loading work.tb_example(bhv)
# Loading work.dut_example(rtl)
# Loading work.pltbutils_clkgen(bhv)
# Loading work.tc_example(tcl)
#
# --- START OF SIMULATION ---
# Testcase: tcl
# 0 ps
#
# Test 1: Reset test (0 ps)
# Done with test 1: Reset test (15000 ps)
#
# Test 2: Simple sum test (15000 ps)
# Done with test 2: Simple sum test (35000 ps)
#
# Test 3: Simple carry in test (35000 ps)
# ** Error: Check 5; Sum; Actual=0x03 Expected=0x04 in test 3 Simple carry in test
# Time: 55 ns Iteration: 1 Instance: /tb_example/tc0
# Done with test 3: Simple carry in test (55000 ps)
#
# Test 4: Simple carry out test (55000 ps)
# Done with test 4: Simple carry out test (75000 ps)
#
# --- END OF SIMULATION ---
# Note: the results presented below are based on the PITbUtil's check() procedure calls.
# The design may contain more errors, for which there are no check() calls.
# 75 ns
# 4 Tests
# 8 Checks
# 1 Errors
# *** FAIL ***
VSIM(paused)>
```

The transcript says that one error has been found at 55 ns, in test 3; Simple carry in test.


```
x <= resize(unsigned(x_i), G_WIDTH+1);
y <= resize(unsigned(y_i), G_WIDTH+1);
c <= resize(unsigned(std_logic_vector('0' & carry_i)), G_WIDTH+1);

p_sum : process(clk_i)
begin
  if rising_edge(clk_i) then
    if rst_i = '1' then
      sum <= (others => '0');
    else
      if G_DISABLE_BUGS = 1 then
        sum <= x + y + c;
      else
        sum <= x + y;
      end if;
    end if;
  end if;
end process;
```


It looks like if the generic `G_DISABLE_BUGS` is not one, the carry input is not added to the sum. The simple way to disable this bug, is to set the generic `G_DISABLE_BUGS` to one. In this case, this can be done very easily, without any coding.

In the ModelSim transcript window, type

```
do run_tc1_bugfixed.do
```


This will run the test again, but now with the generic `G_DISABLE_BUGS` set to 1.

The transcript and waveform windows will now look like this:



```

Transcript
File Edit View Window
Transcript
# -- Loading entity tc_example
# vsim -l ../log/tcl.log -GG_DISABLE_BUGS=1 tb_example
# Loading std.standard
# Loading std.textio(body)
# Loading ieee.std_logic_1164(body)
# Loading work.txt_util(body)
# Loading ieee.numeric_std(body)
# Loading work.pltbutils_type_pkg(body)
# Loading work.pltbutils_user_cfg_pkg(body)
# Loading work.pltbutils_func_pkg(body)
# Loading work.pltbutils_comp_pkg
# Loading work.tb_example(bhv)
# Loading work.dut_example(rtl)
# Loading work.pltbutils_clkgen(bhv)
# Loading work.tc_example(tcl)
#
# --- START OF SIMULATION ---
# Testcase: tcl
# 0 ps
#
# Test 1: Reset test (0 ps)
# Done with test 1: Reset test (15000 ps)
#
# Test 2: Simple sum test (15000 ps)
# Done with test 2: Simple sum test (35000 ps)
#
# Test 3: Simple carry in test (35000 ps)
# Done with test 3: Simple carry in test (55000 ps)
#
# Test 4: Simple carry out test (55000 ps)
# Done with test 4: Simple carry out test (75000 ps)
#
# --- END OF SIMULATION ---
# Note: the results presented below are based on the PITbUtil's check() procedure calls.
#       The design may contain more errors, for which there are no check() calls.
#
#       75 ns
#       4 Tests
#       8 Checks
#       0 Errors
# *** SUCCESS ***
VSIM(paused)>
    
```



The PITbUtils files are located in src/vhdl/ .

The files needed to be compiled are listed in pltbutils_files.lst .

See example code in example/vhdl/ .

This code can be simulated from sim/example_sim/run/ .

Template code is available in template/vhdl/ .

This tutorial has shown some of the available procedures and testbench components in PITbUtils. For a complete list, see the reference section.

User Configuration

It is possible to configure some aspects of PITbUtils's behaviour, by modifying the package file `pltbutils_user_cfg.pkg`.

It is recommended NOT to modify the file directly. Instead, copy it to another directory and modify the copy. Make the simulator read the modified copy instead of the original. This makes it easier to update `pltbutils` to a later version without destroying the modifications. After updating, check if anything has changed in the file, and change your modified copy accordingly.

Configuring Simulation Halt

When calling `endsim()`, the signal `stop_sim` is set to '1'. When set, all clock generators etc in the testbench and the DUT should stop, so there will be no further events in the simulation. The simulator will detect that nothing more will happen, and stops the simulation.

In some cases, it is not possible to stop clock generators, PLL models etc. In that case, `endsim()` can force a simulation halt, by setting the `force` argument to true.

The declaration of `endsim()` is

```
procedure endsim(  
    signal pltbutils_sc      : out pltbutils_sc_t;  
    constant show_success_fail : in boolean := false;  
    constant force          : in boolean := false  
);
```

so to force a simulation halt, call `endsim` with

```
endsim(pltbutils_sc, true, true);
```

This stops the simulation using an assert-failure. This works in all versions of VHDL, but it is an ugly way of doing it, since it outputs a failure message for something which isn't a failure.

You can change the way the simulation stops when the `force` flag is set in your copy of `pltbutils_user_cfg.vhd`.

Change the constant `C_PLTBUTILS_USE_CUSTOM_STOPSIM` to true, and modify the behaviour of the procedure `custom_stopsim()`. In VHDL-2008 the new keywords `stop` and `finish` was introduced. Try one of them, for example.

Configuring Messages for Integration Environments

It is possible adapt the status messages to suit various continuous integration environments, e.g. TeamCity, by specifying what the messages should look like.

You can create your own messages printed when starting and stopping a simulation, starting and stopping a test, for checking, etc.

In your copy of `pltbutils_user_cfg_pkg.vhd`, set one or more of the message constants to true, and modify the associated procedure.

The constants are

```
C_PLTBUTILS_USE_CUSTOM_STARTSIM_MSG  
C_PLTBUTILS_USE_CUSTOM_ENDSIM_MSG  
C_PLTBUTILS_USE_CUSTOM_STARTTEST_MSG  
C_PLTBUTILS_USE_CUSTOM_ENDTEST_MSG  
C_PLTBUTILS_USE_CUSTOM_CHECK_MSG  
C_PLTBUTILS_USE_CUSTOM_ERROR_MSG
```

The corresponding procedures already contain examples for TeamCity. Modify if you use another environment.

You can disable the standard messages by setting the standard constants to false (`C_PLTBUTILS_USE_STD_STARTSIM_MSG` etc).

3

Reference

Functions and procedures

startsim

```
procedure startsim(  
    constant testcase_name    : in    string;  
    signal   pltbutils_sc     : out   pltbutils_sc_t  
)
```

Displays a message at start of simulation message, and initializes PITbUtils' global status and control signal. Call startsim() only once.

Arguments:

testcase_name	Name of the test case, e.g. "tc1".
pltbutils_sc	PITbUtils' global status- and control signal. Must be set to pltbutils_sc.

The start-of-simulation message is not only intended to be informative for humans. It is also intended to be searched for by scripts, e.g. for collecting results from a large number of regression tests.

Example:

```
startsim("tc1", pltbutils_sc);
```


endsim

```
procedure endsim(  
    signal  pltbutils_sc      : out pltbutils_sc_t;  
    constant show_success_fail : in  boolean := false;  
    constant force            : in  boolean := false  
)
```

Displays a message at end of simulation message, presents the simulation results, and stops the simulation. Call endsim() it only once.

Arguments:

pltbutils_sc	PITbUtils' global status- and control signal. Must be set to pltbutils_sc.
show_success_fail	If true, endsim() shows "**** SUCCESS ****", "**** FAIL ****", or "**** NO CHECKS ****". Optional, default is false.
force	If true, forces the simulation to stop using an assert failure statement. Use this option only if the normal way of stopping the simulation doesn't work (see below). Optional, default is false.

The testbench should be designed so that all clocks stop when endsim() sets the signal stop_sim to '1'. This should stop the simulator.

In some cases, that doesn't work, then set the force argument to true, which causes a false assert failure, which should stop the simulator.

The end-of-simulation messages and success/fail messages are not only intended to be informative for humans. They are also intended to be searched for by scripts, e.g. for collecting results from a large number of regression tests.

Examples:

```
endsim(pltbutils_sc);  
endsim(pltbutils_sc, true);  
endsim(pltbutils_sc, true, true);
```

starttest

```
procedure starttest(  
    constant num          : in    integer := -1;  
    constant name         : in    string;  
    signal  pltbutils_sc  : out   pltbutils_sc_t  
)
```

Sets a number (optional) and a name for a test. The number and name will be printed to the screen, and displayed in the simulator's waveform window.

The test number and name is also included if there errors reported by the check() procedure calls.

Arguments:

num	Test number. Optional, default is to increment the current test number.
name	Test name.
pltbutils_sc	PITbUtils' global status- and control signal. Must be set to pltbutils_sc.

If the test number is omitted, a new test number is automatically computed by incrementing the current test number. Manually setting the test number may make it easier to find the test code in the testbench code, though.

Examples:

```
starttest("Reset test", pltbutils_sc);  
starttest(1, "Reset test", pltbutils_sc);
```

endtest

```
procedure endtest(  
    signal pltbutils_sc      : out  pltbutils_sc_t  
)
```

Prints an end-of-test message to the screen.

Arguments:

pltbutils_sc PITbUtils' global status- and control signal.
 Must be set to pltbutils_sc.

Example:

```
endtest(pltbutils_sc);
```

print printv print2

```

procedure print(
    signal    s                : out    string;
    constant txt              : in     string
)

procedure print(
    constant active           : in     boolean;
    signal    s                : out    string;
    constant txt              : in     string
)

procedure print(
    signal    pltbutils_sc     : out    pltbutils_sc_t;
    constant txt              : in     string
)

procedure print(
    constant active           : in     boolean;
    signal    pltbutils_sc     : out    pltbutils_sc_t;
    constant txt              : in     string
)

procedure printv(
    variable s                : out    string;
    constant txt              : in     string
)

procedure printv(
    constant active           : in     boolean;
    variable s                : out    string;
    constant txt              : in     string
)
    
```

```

procedure print2(
    signal    s                : out    string;
    constant txt              : in     string
)

procedure print2(
    constant active          : in     boolean;
    signal    s              : out    string;
    constant txt              : in     string
)

procedure print2(
    signal    pltbutils        : out    pltbutils_sc_t;
    constant txt              : in     string
)

procedure print2(
    constant active          : in     boolean;
    signal    pltbutils        : out    pltbutils_sc_t;
    constant txt              : in     string
)
    
```

print() prints text messages to a signal for viewing in the simulator's waveform window. printv() does the same thing, but to a variable instead. print2() prints both to a signal and to the transcript window.

The type of the output can be string or pltbutils_sc_t. If the type is pltbutils_sc_t, the name can be no other than pltbutils_sc.

Arguments:

s	Signal or variable of type string to be printed to.
txt	The text.
active	The text is only printed if active is true. Useful for debug switches, etc.
pltbutils_sc	PITbUtils' global status- and control signal of type pltbutils_sc_t. The name must be no other than pltbutils_sc.

If the string txt is longer than the signal s, the text will be truncated. If txt is shorter, s will be padded with spaces.

NOTE: more print procedures are available in txt_util.txt .

Examples:

```
print(msg, "Hello, world"); -- Prints to signal msg
print(G_DEBUG, msg, "Hello, world"); -- Prints to signal msg if
                                     -- generic G_DEBUG is true
printv(v_msg, "Hello, world"); -- Prints to variable msg
print(pltbutils_sc, "Hello, world"); -- Prints to "info" in waveform
                                     -- window
print2(msg, "Hello, world"); -- Prints to signal and transcript window
print(pltbutils_sc, "Hello, world"); -- Prints to "info" in waveform and
                                     -- transcript windows
```

waitclks

```
procedure waitclks(  
    constant n                : in    natural;  
    signal   clk              : in    std_logic;  
    signal   pltbutils_sc     : out   pltbutils_sc_t;  
    constant falling         : in    boolean := false;  
    constant timeout         : in    time   := C_PLTBUTILS_TIMEOUT  
)
```

Waits specified amount of clock cycles of the specified clock. Or, to be more precise, a specified number of specified clock edges of the specified clock.

Arguments:

n	Number of rising or falling clock edges to wait.
clk	The clock to wait for.
pltbutils_sc	PITbUtils' global status- and control signal. Must be set to pltbutils_sc.
falling	If true, waits for falling edges, otherwise rising edges. Optional, default is false.
timeout	Timeout time, in case the clock is not working. Optional, default is C_PLTBUTILS_TIMEOUT.

Examples:

```
waitclks(5, sys_clk, pltbutils_sc);  
waitclks(5, sys_clk, pltbutils_sc, true);  
waitclks(5, sys_clk, pltbutils_sc, true, 1 ms);
```

waitsig

```
procedure waitsig(  
  signal    s                : in  
             integer|std_logic|std_logic_vector|unsigned|signed;  
  constant value            : in  
             integer|std_logic|std_logic_vector|unsigned|signed;  
  signal    clk              : in    std_logic;  
  signal    pltbutils_sc     : out   pltbutils_sc_t;  
  constant falling          : in    boolean := false;  
  constant timeout         : in    time   := C_PLTBUTILS_TIMEOUT)
```

Waits until a signal has reached a specified value after specified clock edge.

Arguments:

s	The signal to test. Supported types: integer, std_logic, std_logic_vector, unsigned, signed.
value	Value to wait for. Same type as data or integer.
clk	The clock.
pltbutils_sc	PITbUtils' global status- and control signal. Must be set to pltbutils_sc.
falling	If true, waits for falling edges, otherwise rising edges. Optional, default is false.
timeout	Timeout time, in case the clock is not working. Optional, default is C_PLTBUTILS_TIMEOUT.

Examples:

```
waitsig(wr_en, '1', sys_clk, pltbutils_sc);  
waitsig(rd_en, 1, sys_clk, pltbutils_sc, true);  
waitclks(full, '1', sys_clk, pltbutils_sc, true, 1 ms);
```


check

```
procedure check(  
    constant rpt          : in    string;  
    constant data         : in    integer |  
                           std_logic | std_logic_vector |  
                           unsigned | signed;  
    constant expected     : in    integer |  
                           std_logic | std_logic_vector |  
                           unsigned | signed;  
    signal  pltbutils_sc  : out   pltbutils_sc_t  
)
```

```
procedure check(  
    constant rpt          : in    string;  
    constant data         : in    std_logic_vector;  
    constant expected     : in    std_logic_vector;  
    constant mask         : in    std_logic_vector;  
    signal  pltbutils_sc  : out   pltbutils_sc_t  
)
```

```
procedure check(  
    constant rpt          : in    string;  
    constant expr         : in    boolean;  
    signal  pltbutils_sc  : out   pltbutils_sc_t  
)
```

Checks that the value of a signal or variable is equal to expected. If not equal, displays an error message and increments the error counter.

Arguments:

rpt	Report message to be displayed in case of mismatch. It is recommended that the message is unique and that it contains the name of the signal or variable being checked. The message should NOT contain the expected value, because check() prints that automatically.
data	The signal or variable to be checked. Supported types: integer, std_logic, std_logic_vector, unsigned, signed.
expected	Expected value. Same type as data, or integer.
mask	Bit mask and:ed to data and expected before comparison. Optional if data is std_logic_vector. Not allowed for other types.
expr	boolean expression for checking. This makes it possible to check any kind of expression, not just equality.
pltbutils_sc	PITbUtils' global status- and control signal. Must be set to the name pltbutils_sc.

Examples:

```

check("dat_o after reset", dat_o, 0, pltbutils_sc);
-- With mask:
check("Status field in reg_o after start", reg_o, x"01", x"03",
      pltbutils_sc);
-- Boolean expression:
check("Counter after data burst", cnt_o > 10, pltbutils_sc);
    
```

Testbench components

pltbutils_clkgen

Creates a clock for use in a testbench. The clock stops when input port stop_sim goes '1'. This makes the simulator stop (unless there are other infinite processes running in the simulation).

Generic	Width	Type	Description
G_PERIOD	1	time	Clock period.
G_INITVALUE	1	std_logic	Initial value of the non-inverted clock output.

Port	Width	Direction	Description
clk_o	1	Output	Non-inverted clock output. Use this output for single ended or differential clocks.
clk_n_o	1	Output	Inverted clock output. Use if a differential clock is needed, leave open if single-ended clock is needed.
stop_sim_i	1	Input	When '1', stops the clock. This will normally stop the simulation.