



Lecture 12

ALU (3) - Division Algorithms

Sommersemester 2002

Leitung: Prof. Dr. Mirosław Malek

www.informatik.hu-berlin.de/rok/ca

FIXED-POINT, FLOATING-POINT ARITHMETIC AND LOGICAL FUNCTIONS

A. FIXED-POINT ARITHMETIC (continued)

- RESTORING DIVISION**
- NONRESTORING DIVISION**
- DIVISION BY REPEATED MULTIPLICATION**
- DIVISION BY USING RECIPROCAL (CRAY)**


B. FLOATING-POINT ARITHMETIC

- FORMATS**
- ADDITION/SUBTRACTION**
- MULTIPLICATION/DIVISION**


C. LOGIC FUNCTIONS

ALGORITHM FOR RESTORING DIVISION


- DO n TIMES
- SHIFT A & Q LEFT ONE BINARY POSITION
- SUBTRACT M FROM A, PLACING THE ANSWER BACK IN A
- IF THE SIGN OF A IS 1, SET q_0 TO 0 AND ADD M BACK TO A (RESTORE A);
- OTHERWISE, SET q_0 TO 1



RESTORING DIVISION ALGORITHM FOR POSITIVE INTEGERS



A
R
E
S
T
O
R
I
N
G
D
I
V
I
S
I
O
N
E
X
A
M
P
L
E



NONRESTORING DIVISION

ALGORITHM FOR NONRESTORING DIVISION

- STEP 1: DO n TIMES
 - IF THE SIGN OF A IS 0, SHIFT A AND Q LEFT ONE BINARY POSITION AND SUBTRACT M FROM A;
 - OTHERWISE, SHIFT A AND Q LEFT AND ADD M TO A. IF THE SIGN OF A IS 0, SET Q_0 TO 1; OTHERWISE SET Q_0 TO 0.

- STEP 2: IF THE SIGN OF A IS 1, ADD M TO A

- The negative result is restored by adding, i.e.,

$$R_i \leftarrow (R_i - M) + M \quad (1)$$


- and is followed by a shift left one (i.e., multiplication by 2) and subtract:

$$R_{i+1} \leftarrow 2R_i - M \quad (2)$$


- The two operations (1) and (2) are then merged into a single one:

$$R_{i+1} \leftarrow 2[(R_i - M) + M] - M = 2R_i - M$$

A NONRESTORING DIVISION ALGORITHM FOR POSITIVE INTEGERS



A NONRESTORING DIVISION EXAMPLE



DIVISION BY REPEATED MULTIPLICATION

$$Q = \frac{\text{DIVIDEND} \times F_0 \times F_1 \times \dots}{\text{DIVISOR} \times F_0 \times F_1 \times \dots}$$

$$\text{DIVISOR} = V = 1-y$$

$$F_0 = 1+y$$

$$F_1 = 1+y^2$$


$$V \times F_0 = 1-y^2$$

$$V \times F_0 \times F_1 = (1-y^2)(1+y^2) = 1-y^4$$

Multiply top & bottom by $(1+y)$, then $(1+y^2)$, ...

$$\frac{1}{x} = \frac{1}{1-y} = \frac{1+y}{1-y^2} = \frac{(1+y)(1+y^2)}{1-y^4}$$

$$\frac{1}{x} = \frac{(1+y)(1+y^2)(1+y^4)\dots(1+y^{2^{i-1}})}{1-y^{2^i}}$$



0

Key idea:

- Find a simple function (factor) so that by a repeated multiplication the value approaches 1

FLOATING-POINT ARITHMETIC (scientific notation)

COMPONENTS OF A FLOATING-POINT NUMBER REPRESENTATION

- Sign
- Exponent (X_e) (Y_e)
- Mantissa (X_m) (Y_m)

$$X = X_m * B^{X_e}$$

Examples:

$$+ 1.23 * 10^2$$

$$9.999\ 999 \times 10^{99}$$

a. **Sign** is included as an extension of the mantissa.

b. **Exponent**

(1) **Scale Factor (B) base or radix**

(2) **Biasing.** Exponent values are usually biased about some excess value. For example if we have an exponent field capable of having values 00 to 99 to represent plus and minus values we would assign exponents excess 50. The exponent -50 would be represented by 0, exponent 0 by 50, and exponent 49 by 99.


$$0 \leq E_B \leq 99 \quad \text{Exponent Field}$$

$$-50 \leq E \leq 49 \quad \text{Exponent Represented}$$

The reason for using this technique is that the magnitudes of numbers may be compared without regard to whether the number is in floating-point format or not, i.e., magnitudes are compared in the same way as for integer arithmetic.

FLOATING-POINT NUMBERS FORMATS

a) A 32-bit binary format



b) Binary normalization example

0	0001001	001.....
---	---------	----------

+0.001...x2⁹

Unnormalized value

0	0000111	1.....
---	---------	--------

+0.1...x2⁷

Normalized version

Normalization keeps mantissa at the value of

$$\frac{1}{2} \leq M < 1 \quad -64 \leq E \leq 63$$

excess - 64 format $E' = E + 64$ $0 \leq E' \leq 127$

c) Hexadecimal (base 16) normalization example with excess 64-exponent (bias 64)

1	0000011	00000101.....
---	---------	---------------

-0.00000101...x16³

Unnormalized value

Exception: Underflow $E < 64$ Overflow $E > 63$ - set to 0

1	0000010	0101.....
---	---------	-----------

-0.0101...x16²

Normalized version

THE IEEE STANDARD FORMAT


Value= $(-1)^S \times (1 + M_1 \times 2^{-1} + M_2 \times 2^{-2} + \dots + M_{23} \times 2^{-23}) \times 2^{E_7 \dots E_1 E_0 - 127}$ (short real)

Value= $(-1)^S \times (1 + M_1 \times 2^{-1} + M_2 \times 2^{-2} + \dots + M_{52} \times 2^{-52}) \times 2^{E_{10} \dots E_1 E_0 - 1023}$ (long real)

Value= $(-1)^S \times (M_0 + M_1 \times 2^{-1} + M_2 \times 2^{-2} + \dots + M_{63} \times 2^{-63}) \times 2^{E_{14} \dots E_1 E_0 - 16383}$ (temporary real)

- **Short real (32 bits)**


- Range of value $1,18 \times 10^{-38} < |x| < 3,40 \times 10^{+38}$, precision 24 bits



- S: sign bit (1=negative mantissa, 0=positive mantissa)
- E₇...E₀: exponent (8bits, bias 127)
- M₁...M₂₃: mantissa (23 bits plus implicit M₀=1)

- **Long real (64 bits)**


- Range of value $2,23 \times 10^{-308} < |x| < 1,79 \times 10^{+308}$, precision 53 bits



- bias 1023

- **Temporary real (80 bits)**

- Range of value $3,37 \times 10^{-4932} < |x| < 1,79 \times 10^{+4932}$, precision 53 bits



- bias 16.383

FLOATING-POINT REPRESENTATION IEEE STANDARD

$$(-1)^S (1.M) 2^{E-\text{bias}} \quad (\text{e.g., bias} = 127)$$

S	8-bit exponent	23-bit mantissa
---	----------------	-----------------

(single precision)

Mantissa with implied 1	24 bits	$1 \leq M' < 2$
Largest Error	2^{-24}	
Precision	≈ 7 decimal digits	
Bias	127	
Exponent Range	$-126 \leq E' \leq 127$	
Smallest Number	$2^{-126} = 1.2 * 10^{-38}$	
Largest Number	$(2 - 2^{-23}) 2^{127} = 3.4 * 10^{38}$	

Special Cases

a) Zero	$(-1)^S * 0$	E=0, M=0
b) Infinity	$(-1)^S \infty$	E=255, M=0
c) Not-a-number		E=255, M \neq 0
d) Normalized	$(-1)^S * (1.M) 2^{E-127}$	$0 < E < 255$
e) Unnormalized	$(-1)^S * (0.M) 2^{126}$	E=1, M \neq 0

(This Number cannot be normalized because a shift to the left would cause an underflow.)

Examples

S	Exponent	Mantissa implied 1			
0	10000001	1.00...0	= 1.0	* $2^{129-127}$	= 4.0
0	01111111	1.10...0	= 1.5	* $2^{127-127}$	= 1.5
0	10000000	1.010...0	= 1.25	* $2^{128-127}$	= 2.5

UNDERFLOW AND OVERFLOW

- Underflow occurs when a resulting biased exponent is less than zero (0). In such case the floating point word is set to all zeros.
- Overflow occurs when a resulting biased exponent is greater than the maximum value allowed for the exponent field.
- In both cases an error bit in a status word usually is set or an interrupt enabled so that a program can determine what action to take following an underflow or overflow.

NORMALIZATION AND SCALING

- Normalization is a process assuring the maximum available accuracy of a given floating-point number
- Floating-point arithmetic units are usually designed to handle floating-point numbers in a normalized form. If the numbers are not presented to the unit in normalized form the unit often will not yield the correct result. The normalization of a number is related to the base or radius of the exponent. The normalization of a number must occur in shifts of binary digits in units represented by the base. In normalization a digit must appear in the left most mantissa "radix" position adjacent to the decimal. Each left shift of the mantissa represents a subtraction of 1 from the exponent each right shift an addition of 1 to the exponent.
- Normalization and changing the scale factor works like the pen and pencil method in scientific notation.

Examples :

$$1.27 \times 10^5 = .127 \times 10^6$$

$$0.03 \times 10^2 = .30 \times 10^1$$

$$42.1 \times 10^{-6} = .421 \times 10^{-4}$$

$$0.022 \times 10^{-4} = .220 \times 10^{-5}$$

- For binary shift a single shift by a single position is required while for a hexadecimal shift a shift by four positions necessary (implied radix 16)

DIFFICULTY AND ROUNDING (OFF)

Arithmetic's Difficulty

- Multiplication and division are less complicated than addition or subtraction to implement.
- The addition or subtraction of numbers is complicated by the fact that the smaller number has to be shifted to be decimally aligned with the larger number before the arithmetic operation is performed.

Rounding

Fractional binary arithmetic because of limited bit representation can result in erroneous results. Guard bits or extended precision (larger registers) bits are often used to increase accuracy. The result after an operation is then rounded.

Rounding Methods	Results	Guard Bits	Comments
Chopping (Truncation) The result is not rounded.	.0010 .0010]	110	Biased Error: 0 - Chopped Bits
Normal Rounding A one is added to the results LSB if the result is followed by a 1 guard bit.	.0010 .0011] .0011 .0100]	110 110	Unbiased Error: -1/2 to +1/2 (LSB)
Von Neumann A one bit is set in the results LSB if the result is followed by a guard bit.	.0010 .0011] .0011 .0011]	110 110	More Complex Imp. Unbiased Error: -1 to +1 (LSB)

EQUATIONS FOR FLOATING-POINT OPERATIONS

X_E, Y_E - exponents of X and Y
 X_M, Y_M - mantissas of X and Y

$$\text{ADD} \quad X + Y = (X_M * 2^{X_E - Y_E} + Y_M) * 2^{Y_E}$$

$$\text{SUB} \quad X - Y = (X_M * 2^{X_E - Y_E} - Y_M) * 2^{Y_E}$$

$$\text{MULT} \quad X * Y = (X_M * Y_M) * 2^{X_E + Y_E}$$

$$\text{DIV} \quad X / Y = (X_M * Y_M) * 2^{X_E - Y_E}$$

FLOATING-POINT ARITHMETIC ALGORITHMS

- ADD/SUB
- 1) CHOOSE THE NUMBER WITH SMALLER EXPONENT AND SHIFT IT'S MANTISSA RIGHT A NUMBER OF STEPS EQUAL TO THE DIFFERENCE IN EXPONENTS.
 - 2) SET THE EXPONENT OF THE RESULT EQUAL TO THE LARGE EXPONENT.
 - 3) PERFORM ADDITION-SUBTRACTION ON THE MANTISSAS AND DETERMINE THE SIGN OF THE RESULT.
 - 4) NORMALIZE THE RESULT IF NECESSARY.
 - 5) CHECK FOR OVERFLOW AND UNDERFLOW.

FLOATING-POINT MULTIPLICATION AND DIVISION

MULT 1) ADD EXPONENTS.

2) MULTIPLY MANTISSAS AND DETERMINE SIGN OF RESULT

3) NORMALIZE THE RESULTING VALUE IF NECESSARY

4) CHECK FOR OVERFLOW AND UNDERFLOW

DIV 1) SUBTRACT EXPONENTS

2) DIVIDE MANTISSAS & DETERMINE SIGN OF RESULT


3) NORMALIZE THE RESULTING VALUE IF NECESSARY

4) CHECK FOR OVERFLOW AND UNDERFLOW


OVERFLOW $EXP > + \text{ RANGE}$

UNDERFLOW $EXP < - \text{ RANGE}$


A floating-point arithmetic unit viewed as two fixed-point arithmetic units




Data-processing part of a simple floating-point arithmetic unit




A combined fixed-point and floating-point arithmetic unit




Floating-point adder of the IBM mainframe



Floating-point addition-subtraction unit




FLOATING-POINT ADDITION-SUBTRACTION ALGORITHM




1. Comparison of the exponents by subtraction
2. Alignment of the mantissas by shifting
3. Addition or subtraction of the mantissas
4. Normalization of the result


Tests are performed for overflow and for a zero mantissa in the



PIPELINED VERSION OF THE FLOATING-POINT ADDER




Implementation of four logical instructions AND, OR, EXCLUSIVE-OR and NOT



$$Z = \frac{\bar{c}_1 \bar{c}_2 X Y}{\text{AND}} + \frac{\bar{c}_1 c_2 X + \bar{c}_1 c_2 Y}{\text{OR}} + \frac{c_1 \bar{c}_2 \bar{X} Y + c_1 c_2 X \bar{Y}}{\text{EX - OR}} + \frac{c_1 c_2 \bar{X}}{\text{NOT}}$$

Implementation of two conditional branch instructions SZA (skip on zero accumulator) and SNA (skip on nonzero accumulator)



TEST FOR $A > B$ (or $A < B$)
 AND $A = B$ (or nonequality $A \neq B$)

