

Test Bench for CCounterOprAPI

<< Use of the C++ interface code generator requires a paid license >>

Core description

The core **CCounterOprEvent_T** is a counter controlled by input **iOpr**. There is a template parameter to define the type of the counter, for example if TYPE = ubyte, an 8 bits unsigned counter is created. An event on **iOpr** triggers the execution and its value is used to determine the operation according to the following type:

```
enum Opr_t { cOprNone, cOprReset, cOprUp, cOprDown, cOprLoad };
```

Therefore, if **iOpr** equals **cOprUp** then the counter counts up.


Test bench

This test bench illustrates how a psC core can be tested with a C++ application.

You need to install Visual Studio Community 2019, or higher.

Description


As illustrated on the figure below, the test bench consists of a C++ program communicating with a simulated FPGA, the virtual board, using the **Novakod API**. The API consists of functions to control input ports and read output ports.



A C++ code generator creates a C++ class Wrapper to encapsulate and simplify using the interface for a specific psC application. This example shows how easy it is to test a psC core using a C++ application.

The psC test program

The test program consists of a single component, the core to be tested, and IO connections. The counter operation is controlled by the value of the input **iOpr**.



Novakod API C++ class wrapper

The native API allows a C++ application to communicate with the psC program, but it is low level and difficult to use. The C++ interface generator creates a C++ wrapper class **CCounter** to encapsulate the native API functions. To use the **CCounter** class, the C++ programmer simply creates an object of this class and access the input and output ports by simple function calls. Here are the **CCounter** methods for accessing the psC ports:

```
// iOpr
void Set_iOpr(unsigned char val, bool bEvent); // Set a value w/wo event
void SetEv_iOpr(void);                       // Send an event

// iLoadValue
void Set_iLoadValue(unsigned char val);      // Set a value

// oValue
unsigned char Get_oValue(void);              // Get a value
bool TestEv_oValue(void);                   // Test for an event
```

The C++ test program

This is the complete code of the C++ test program. The class **CCounter** has been automatically generated.

```
#include <windows.h>
#include <iostream>
using namespace std;

#include "api.h"
#include "CCounter.h"

int main(int argc, char* argv[])
{
    int Value = 0;           // Counter value
    char chKey = ' ';       // Pressed key value
    int iLoadValue = 0;     // Load value

    // Operation enum, sane as in psC
    enum Opr_t { cOprNone, cOprReset, cOprUp, cOprDown, cOprLoad };

    // Declare the board interface object
    CCounter oFPGA;

    // Initialize and conect to FPGA board (simulated or real)
    if( oFPGA.Initialize() != 0 )
    {
        cout << "Failed to initialize\n";
        return 1;
    };

    // Send a reset, function start() is executed in each component
    oFPGA.pApi->SendStartEvent( );
}
```

```
// Infinite loop, until quit
while(true)
{
    // Print options
    system("cls");
    cout << "1 - (R)eset\n";
    cout << "2 - (U)p\n";
    cout << "3 - (D)own\n";
    cout << "4 - (L)oad\n";
    cout << "    Load Value: " << iLoadValue << endl << endl;
    cout << "q - (Q)uit\n\n";
    cout << "Counter value " << Value << endl << endl;
    cout << "Select operation: ";

    cin >> chKey;

    // If the user wants to quit
    if((chKey == 'q') || (chKey == 'Q'))
        break; // Exit the while!

    // Allow reception of future events
    oFPGA.pApi->ReStartEventsReception();

    switch(chKey)
    {
        // Reset counter
        case '1':
            oFPGA.Set_iOpr(cOprReset, true);
            break;

        // Up counter
        case '2':
            oFPGA.Set_iOpr(cOprUp, true);
            break;

        // Down counter
        case '3':
            oFPGA.Set_iOpr(cOprDown, true);
            break;

        // Load value
        case '4':
            cout << "\nEnter the load value 0 - 255 : ";
            cin >> iLoadValue;
            oFPGA.Set_iLoadValue(iLoadValue);
            oFPGA.Set_iOpr(cOprLoad, true);
            break;
    } // End switch

    oFPGA.pApi->SendEvents();
    oFPGA.pApi->WaitForEvents();

    Value = oFPGA.Get_oValue();
} // End while

return 0;
}
```

Compiling and running the application


First, you need to compile the psC program and generate the C++ wrapper class **CCounter**:

- 1) Launch Novakod Studio software and open the project.
- 2) Start the simulation, menu **Run → Start**. Accept the build confirmation.
- 3) Select menu: **Tools-> C++ API Code Generator** to generate the C++ class.

The files **api.h**, **CCounter.cpp**, **CCounter.h**, **Conversion.cpp** and **Conversion.h** are generated in the **CppCode** directory. You are now ready to execute the C++ application to test the core:

- 4) Go to the **CppCode** directory and start the Visual Studio solution (TestProject.sln).
- 5) Build the solution and execute the program.

When the C++ application starts, a C++ console appears. The user can choose between five commands in the console input. Try it out!



```
H:\012_OpenCores\simple_customi... - - X
1 - Reset
2 - Up
3 - Down
4 - Load
   Load Value: 0
q - Quit
Counter value 0
Select operation:
```

You can use the Novakod Studio **Watch Window** while using the C++ program. Simply add the ports to the watch window.