

Amber Open Source Project

Amber Project User Guide

May 2013

Table of Contents

1	Amber Project	3
1.1	Project Directory Structure	3
1.2	Amber FPGA System	4
2	Verilog simulations	6
2.1	Installing the Amber project	6
2.2	Installing the Compiler	6
2.3	Running Simulations	7
2.4	Simulation output files	10
2.5	Hardware Tests	12
2.6	C Programs	14
2.7	Linux	16
3	FPGA Synthesis	18
4	Using Boot-Loader	20
4.1	Install and configure Minicom	20
4.2	Configure the FPGA	21
5	License	22

1 Amber Project

The Amber project is a complete processor system implemented on the Xilinx Spartan-6 SP605 FPGA development board. The project is hosted on opencores.org. The project provides a complete hardware and software development system about the Amber processor core. A number of applications, with C source code, are provided as examples of what the system can be used for.

The recommended system for the project is the Xilinx SP605 development board, a PC running CentOS 6.x, the Xilinx ISE 14.5 tool chain (free Webpack version), and the Code Sorcery GNU toolchain for ARM processors. All of these elements are free except for the actual development board which costs around \$500.

1.1 Project Directory Structure

The following table describes the directories and sub-directories located under \$AMBER_BASE.

Table 1 Project directory structure


Directory	Description
doc	Contains all project documentation.
hw	Contains all Verilog source files, simulations and synthesis scripts, and hardware test source files.
hw/fpga	Files relating to FPGA synthesis.
hw/fpga/bin	Contains the FPGA synthesis makefile and supporting scripts.
hw/fpga/bitfiles	This directory is created during the FPGA synthesis process. It is used to store the final bitfile generated at the end of the FPGA synthesis process.
hw/fpga/log	This directory is created during the FPGA synthesis process. It is used to store log files for each step of the FPGA synthesis process.
hw/fpga/work	This directory is created during the FPGA synthesis process. It is used to store temporary files created during the FPGA synthesis process. These files get erased when a new synthesis run is started.
hw/isim	Where tests are run from. The Xilinx iSim Verilog simulator work directory, wave dump and any other simulation output files go in here.
hw/tests	Holds a set of hardware tests written in assembly. These tests focus on verifying the correct operation of the instruction set. If any modifications are made to the Amber core it is important that these tests still pass.
hw/tools	Holds scripts used to run Verilog simulations.
hw/vlog	Verilog source files.
hw/vlog/amber23	Amber 23 core Verilog source files.
hw/vlog/amber25	Amber 25 core Verilog source files.
hw/vlog/ethmac	The Ethernet MAC Verilog source files. These files come from the Opencores Ethmac project and are reproduced here for convenience.
hw/vlog/lib	Hardware library Verilog files including memory models. The Amber project provides a simple generic library that is normally used for simulations. It also provides some wrappers for Xilinx library elements.
hw/vlog/system	FPGA system Verilog source files.
hw/vlog/tb	Testbench Verilog files.
hw/vlog/xs6_ddr3	Xilinx Spartan-6 DDR3 controller Verilog files go in here. These are not provided with the project for copyright reasons. They are needed to implement the Amber system on a Spartan-6 development board and must be generated in Xilinx Coregen.
hw/vlog/xv6_ddr3	Xilinx Virtex-6 DDR3 controller Verilog files go in here. These are not provided with the

Directory	Description
	project for copyright reasons. They are needed to implement the Amber system on a Virtex-6 development board and must be generated in Xilinx Coregen.
sw	Contains C source files for applications that run on the Amber system, as well as some utilities that aid in debugging the system.
sw/boot-loader-serial	C, assembly sources and a makefile for the serial-port boot-loader application.
sw/boot-loader-ethmac	C, assembly sources and a makefile for the ethernet-port boot-loader application. This application supports telnet for control and status, and tftp for uploading elf executable files.
sw/hello-world	C, assembly source and a makefile for a simple stand-alone application example.
sw/include	Common C, assembly and makefile include files.
sw/mini-libc	C, assembly sources and a makefile to build the object that comprise a very small and limited stand-alone replacement for the libc library.
sw/tools	Shell scripts and C source files for compile and debug utilities.
sw/vmlinux	Contains the .mem and .dis files for the vmlinux simulation.

1.2 Amber FPGA System

The FPGA system included with the Amber project is a complete embedded processor system which included all peripherals needed to run Linux, including UART, timers and an Ethernet (MII) port. The following diagram shows the entire system.

Figure 1 - Amber FPGA System



All the Verilog source code was specially developed for this project with the exception of the following modules;

- *ddr3.v*. The Xilinx Spartan-6 DDR3 controller was generated by the Xilinx Coregen tool. The files are not included with the project for copyright reasons. It is up to the user to obtain the ISE software from Xilinx and generate the correct memory controller. Note that Wishbone bridge modules are included that support both the Xilinx Spartan-6 DDR3 controller and the Virtex-6 controller.
- *eth_top.v*. This module is from the Opencores Ethernet MAC 10/100 Mbps project. The Verilog code is included for convenience. It has not been modified, except to provide a memory module for the Spartan-6 FPGA.

2 Verilog simulations

2.1 Installing the Amber project

If you have not already done so, you need to download the Amber project from Opencores.org. The Amber project includes all the Verilog source files, tests written in assembly, a boot loader application written in C and scripts to compile, simulate and synthesize the code. You can either download a tar.gz file from the Opencores website or better still, connect to the Opencores Subversion server to download the project. This can be done on a Linux PC as follows;

```
$ mkdir /<your amber install path>/
$ cd /<your amber install path>/
$ svn --username <your opencores account name> --password <your opencores password> \
  co http://opencores.org/ocsvn/amber/amber/trunk
```

2.2 Installing the Compiler

Tests need to be compiled before you can run simulations. You need to install a GNU cross-compiler to do this. The easiest way to install the GNU tool chain is to download a ready made package. Code Sourcery provides a free one. To download the Code Sourcery package, go to this page

<http://www.codesourcery.com/sgpp/lite/arm>

You need to register and will be sent an email to access the download area. Select the **GNU/Linux** version and then the **IA32 GNU/Linux** Installer. Once the package is installed, add the following to your .bashrc file, where the PATH is set to where you install the Code Sourcery GNU package.

```
# Change /proj/amber to where you saved the amber package on your system
export AMBER_BASE=/<your amber install path>/trunk

# Change /opt/Sourcery to where the package is installed on your system
PATH=/<your code sourcery install path>/bin:${PATH}

# AMBER_CROSSTOOL is the name added to the start of each GNU tool in
# the Code Sourcery bin directory. This variable is used in various makefiles to set
# the correct tool to compile code for the Amber core
export AMBER_CROSSTOOL=arm-none-linux-gnueabi

# Xilinx ISE installation directory
# This should be configured for you when you install ISE.
# But check that it has the correct value
# It is used in the run script to locate the Xilinx library elements.
export XILINX=/opt/Xilinx/14.5/ISE
```

2.2.1 GNU Tools Usage

It's important to remember to use the correct switches with the GNU tools to restrict the ISA to the set of instructions supported by the Amber 2 core. The switches are already set in the makefiles included with the Amber 2 core. Here are the switches to use with gcc (arm-none-linux-gnueabi-gcc);

```
-march=armv2a -mno-thumb-interwork
```

These switches specify the correct version of the ISA, and tell the compiler not to create bx instructions. Here is the switch to use with the GNU linker, arm-none-linux-gnueabi-ld;

```
--fix-v4bx
```

This switch converts any bx instructions (which are not supported) to 'mov pc, lr'. Here is an example usage from the boot-loader make process;

```
arm-none-linux-gnueabi-gcc -c -Os -march=armv2a -mno-thumb-interwork -ffreestanding
-I../include -c -o boot-loader.o boot-loader.c
arm-none-linux-gnueabi-gcc -I../include -c -o start.o start.S
arm-none-linux-gnueabi-gcc -c -Os -march=armv2a -mno-thumb-interwork -ffreestanding
-I../include -c -o crc16.o crc16.c
arm-none-linux-gnueabi-gcc -c -Os -march=armv2a -mno-thumb-interwork -ffreestanding
-I../include -c -o xmodem.o xmodem.c
arm-none-linux-gnueabi-gcc -c -Os -march=armv2a -mno-thumb-interwork -ffreestanding
-I../include -c -o elfsplitter.o elfsplitter.c
arm-none-linux-gnueabi-ld -Bstatic -Map boot-loader.map --strip-debug --fix-v4bx -o boot-
loader.elf -T sections.lds boot-loader.o start.o crc16.o xmodem.o elfsplitter.o
../mini-libc/printf.o ../mini-libc/libc_asm.o ../mini-libc/memcpy.o
arm-none-linux-gnueabi-objcopy -R .comment -R .note boot-loader.elf
../tools/amber-elfsplitter boot-loader.elf > boot-loader.mem
../tools/amber-memparams.sh boot-loader.mem boot-loader_memparams.v
arm-none-linux-gnueabi-objdump -C -S -EL boot-loader.elf > boot-loader.dis
```

A full list of compile switches for gcc can be found here;

<http://gcc.gnu.org/onlinedocs/gcc-4.5.2/gcc/ARM-Options.html#ARM-Options>

And for ld here;

<http://sourceware.org/binutils/docs-2.21/ld/ARM.html#ARM>

2.3 Running Simulations

You should be able to use any Verilog-2001 compatible simulator to run simulations. The project comes with run scripts and project files for the free Xilinx Webpack ISim 14.5 simulator.

Example usage:

```
$ cd $AMBER_BASE/hw/isim
$ ./run.sh hello-world
Test hello-world, type 4
make -s -C ../mini-libc MIN_SIZE=1
arm-none-linux-gnueabi-gcc -c -Os -march=armv2a -mno-thumb-interwork -ffreestanding
-I../include -c -o boot-loader-serial.o boot-loader-serial.c
arm-none-linux-gnueabi-ld -Bstatic -Map boot-loader-serial.map --strip-debug --fix-
v4bx -o boot-loader-serial.elf -T sections.lds boot-loader-serial.o start.o crc16.o
xmodem.o elfsplitter.o ../mini-libc/printf.o ../mini-libc/libc_asm.o ../mini-
libc/memcpy.o
arm-none-linux-gnueabi-objcopy -R .comment -R .note boot-loader-serial.elf
../tools/amber-elfsplitter boot-loader-serial.elf > boot-loader-serial.mem
../tools/amber-memparams32.sh boot-loader-serial.mem boot-loader-serial_memparams32.v
../tools/amber-memparams128.sh boot-loader-serial.mem boot-loader-
serial_memparams128.v
arm-none-linux-gnueabi-objdump -C -S -EL boot-loader-serial.elf > boot-loader-
serial.dis
../tools/check_mem_size.sh boot-loader-serial.mem "@000020"
make -s -C ../mini-libc MIN_SIZE=1
Running: /tools/Xilinx/14.5/ISE_DS/ISE/bin/lin/unwrapped/fuse tb -o amber-test.exe
-prj amber-isim.prj -d BOOT_MEM_FILE="../../sw/boot-loader-serial/boot-loader-
serial.mem" -d BOOT_MEM_PARAMS_FILE="../../sw/boot-loader-serial/boot-loader-
serial_memparams32.v" -d MAIN_MEM_FILE="../../sw/hello-world/hello-world.mem" -d
AMBER_LOG_FILE="tests.log" -d AMBER_TEST_NAME="hello-world" -d AMBER_SIM_CTRL=4 -d
AMBER_TIMEOUT=0 -d AMBER_LOAD_MAIN_MEM -incremental -i ../vlog/lib -i ../vlog/system
```

```
-i ../vlog/amber23 -i ../vlog/amber25 -i ../vlog/tb
ISim P.58f (signature 0xfbc00daa)
Number of CPUs detected in this system: 4
Turning on mult-threading, number of parallel sub-compilation jobs: 8
Determining compilation order of HDL files
Analyzing Verilog file "../vlog/system/boot_mem32.v" into library work
Analyzing Verilog file "../vlog/system/boot_mem128.v" into library work
Analyzing Verilog file "../vlog/system/clocks_resets.v" into library work
Analyzing Verilog file "../vlog/system/interrupt_controller.v" into library work
Analyzing Verilog file "../vlog/system/system.v" into library work
Analyzing Verilog file "../vlog/system/test_module.v" into library work
Analyzing Verilog file "../vlog/system/timer_module.v" into library work
Analyzing Verilog file "../vlog/system/uart.v" into library work
Analyzing Verilog file "../vlog/system/wb_xs6_ddr3_bridge.v" into library work
Analyzing Verilog file "../vlog/system/wishbone_arbiter.v" into library work
Analyzing Verilog file "../vlog/system/afifo.v" into library work
Analyzing Verilog file "../vlog/system/ddr3_afifo.v" into library work
Analyzing Verilog file "../vlog/system/ethmac_wb.v" into library work
Analyzing Verilog file "../vlog/system/main_mem.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_clockgen.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_crc.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_fifo.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_maccontrol.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_macstatus.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_miim.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_outputcontrol.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_random.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_receivecontrol.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_registers.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_register.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_rxaddrcheck.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_rxcounters.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_rxethmac.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_rxstatem.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_shiftreg.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_spram_256x32.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_top.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_transmitcontrol.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_txcounters.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_txethmac.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_txstatem.v" into library work
Analyzing Verilog file "../vlog/ethmac/eth_wishbone.v" into library work
Analyzing Verilog file "../vlog/ethmac/xilinx_dist_ram_16x32.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_alu.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_barrel_shift.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_cache.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_coprocessor.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_core.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_decode.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_decompile.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_execute.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_fetch.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_multiply.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_register_bank.v" into library work
Analyzing Verilog file "../vlog/amber23/a23_wishbone.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_alu.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_barrel_shift.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_shifter.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_coprocessor.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_core.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_dcache.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_decode.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_decompile.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_execute.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_fetch.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_icache.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_mem.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_multiply.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_register_bank.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_wishbone.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_wishbone_buf.v" into library work
Analyzing Verilog file "../vlog/amber25/a25_write_back.v" into library work
Analyzing Verilog file "../vlog/lib/generic_iobuf.v" into library work
Analyzing Verilog file "../vlog/lib/generic_sram_byte_en.v" into library work
Analyzing Verilog file "../vlog/lib/generic_sram_line_en.v" into library work
Analyzing Verilog file "../vlog/tb/tb_uart.v" into library work
Analyzing Verilog file "../vlog/tb/eth_test.v" into library work
Analyzing Verilog file "../vlog/tb/dumpvcd.v" into library work
Analyzing Verilog file "../vlog/tb/tb.v" into library work
Starting static elaboration
Completed static elaboration
Fuse Memory Usage: 41692 KB
Fuse CPU Usage: 1220 ms
Compiling module clocks_resets
Compiling module generic_sram_line_en(DATA_WIDTH=...
```



```
Compiling module generic_sram_byte_en(DATA_WIDTH=...
Compiling module a23_cache_default
Compiling module a23_wishbone
Compiling module a23_fetch
Compiling module a23_decompile_2
Compiling module a23_decode
Compiling module a23_barrel_shift
Compiling module a23_alu
Compiling module a23_multiply
Compiling module a23_register_bank
Compiling module a23_execute
Compiling module a23_coprocessor
Compiling module a23_core
Compiling module eth_clockgen
Compiling module eth_shiftreg
Compiling module eth_outputcontrol
Compiling module eth_miim
Compiling module eth_register(RESET_VALUE=8'b0)
Compiling module eth_register(RESET_VALUE=8'b1010...
Compiling module eth_register(WIDTH=1,RESET_VALUE...
Compiling module eth_register(WIDTH=7,RESET_VALUE...
Compiling module eth_register(WIDTH=7,RESET_VALUE...
Compiling module eth_register(WIDTH=7,RESET_VALUE...
Compiling module eth_register(RESET_VALUE=8'b0110...
Compiling module eth_register(RESET_VALUE=8'b0100...
Compiling module eth_register(WIDTH=6,RESET_VALUE...
Compiling module eth_register(WIDTH=4,RESET_VALUE...
Compiling module eth_register(WIDTH=3,RESET_VALUE...
Compiling module eth_register(RESET_VALUE=8'b0110...
Compiling module eth_register(WIDTH=1)
Compiling module eth_register(WIDTH=5,RESET_VALUE...
Compiling module eth_register(WIDTH=16,RESET_VALU...
Compiling module eth_registers
Compiling module eth_receivecontrol
Compiling module eth_transmitcontrol
Compiling module eth_maccontrol
Compiling module eth_txcounters
Compiling module eth_txstatem
Compiling module eth_crc
Compiling module eth_random
Compiling module eth_txethmac
Compiling module eth_rxstatem
Compiling module eth_rxcounters
Compiling module eth_rxaddrcheck
Compiling module eth_rxethmac
Compiling module generic_sram_byte_en(DATA_WIDTH=...
Compiling module eth_sram_256x32
Compiling module eth_fifo(DEPTH=16,CNT_WIDTH=5)
Compiling module eth_wishbone
Compiling module eth_macstatus
Compiling module eth_top
Compiling module generic_iobuf
Compiling module generic_sram_byte_en(DATA_WIDTH=...
Compiling module boot_mem32
Compiling module uart(WB_DWIDTH=32,WB_SWIDTH=4)
Compiling module test_module(WB_DWIDTH=32,WB_SWID...
Compiling module timer_module(WB_DWIDTH=32,WB_SWI...
Compiling module interrupt_controller(WB_DWIDTH=3...
Compiling module main_mem(WB_DWIDTH=32,WB_SWIDTH=...
Compiling module wishbone_arbiter(WB_DWIDTH=32,WB...
Compiling module ethmac_wb(WB_DWIDTH=32,WB_SWIDTH...
Compiling module system
Compiling module eth_test
Compiling module tb_uart_default
Compiling module dumpvcd
Compiling module tb
Time Resolution for simulation
is 1ps.
Waiting for 1 sub-compilation(s) to finish...
Compiled 68 Verilog Units
Built simulation executable amber-test.exe
Fuse Memory Usage: 89580 KB
Fuse CPU Usage: 2120 ms
GCC CPU Usage: 1200 ms
ISim P.58f (signature 0xfbc00daa)
WARNING: A WEBPACK license was found.
WARNING: Please use Xilinx License Configuration Manager to check out a full ISim
license.
WARNING: ISim will run in Lite mode. Please refer to the ISim documentation for more
information on the differences between the Lite and the Full version.
This is a Lite version of ISim.
Time resolution is 1 ps
Simulator is doing circuit initialization process.
Load boot memory from ../../sw/boot-loader-serial/boot-loader-serial.mem
Read in 2053 lines
```

```

log file tests.log, timeout 0, test name hello-world
Load main memory from ../../sw/hello-world/hello-world.mem
Read in 9116 lines
Finished circuit initialization process.
Amber Boot Loader v20130428143120
j 0x00008000

Hello, World!

-----
Amber Core
> User      FIRQ      IRQ      SVC
r0          0x00000010
r1          0x00008dfc
r2          0x00000000
r3          0x00000000
r4          0x0c008003
r5          0xdeadbeef
r6          0xdeadbeef
r7          0xdeadbeef
r8          0xdeadbeef 0xdeadbeef
r9          0xdeadbeef 0xdeadbeef
r10         0x00000011 0xdeadbeef
r11         0xf0000000 0xdeadbeef
r12         0x00001ecc 0xdeadbeef
r13         0x08000000 0xdeadbeef 0xdeadbeef 0x01ffffb0
r14 (1r)    0x00008020 0xdeadbeef 0xdeadbeef 0x600003fb
r15 (pc)    0x00008490

Status Bits: N=0, Z=1, C=1, V=0, IRQ Mask 0, FIRQ Mask 0, Mode = User
-----

+++++
Passed hello-world 47634 ticks
+++++
Stopped at time : 1191327500 ps : File "/proj/amber_trunk_working/hw/vlog/tb/tb.v"
Line 503

```

2.4 Simulation output files

2.4.1 Disassembly Output File

The disassembly file, `amber.dis`, is generated by default during a simulation. It is located in the `$AMBER_BASE/hw/sim` directory. This file is very useful for debugging software as it shows every instruction executed by the core and the result of all load and store operations.

This file is generated by default. To turn off generation, comment the line where `AMBER_DECOMPILE` is defined in `$AMBER_BASE/hw/vlog/amber/amber_config_defines.v`.

Below is an example of the disassembly output file. The first column gives the time that the instruction was executed. The time is specified in `sys_clk` ticks. The second column gives the address of the instruction being executed and the next column gives the instruction. If an instruction is not executed because of a conditional execution code, this is marked with a '-' character in front of the instruction. For load and store instructions, the actual memory access is given below the instruction. This is the complete listing for the add test.

```

264      0:  mov    r1, #3
267      4:  mov    r2, #1
270      8:  add    r3, r1, r2
273      c:  cmp    r3, #4
276     10: -movne r10, #10
279     14: -bne   b4

```

```

282      18:  mov    r4, #0
285     1c:  mov    r5, #0
288     20:  add   r6, r5, r4
291     24:  cmp   r6, #0
294     28:  -movne r10, #20
297     2c:  -bne  b4
300     30:  mov   r7, #0
303     34:  mvn   r8, #0
306     38:  add   r9, r7, r8
309     3c:  cmn   r9, #1
312     40:  -movne r10, #30
315     44:  -bne  b4
318     48:  mvn   r1, #0
321     4c:  mov   r2, #0
324     50:  add   r3, r1, r2
327     54:  cmn   r3, #1
330     58:  -movne r10, #40
333     5c:  -bne  b4
336     60:  mvn   r4, #0
339     64:  mvn   r5, #0
342     68:  add   r6, r4, r5
345     6c:  cmn   r6, #2
348     70:  -movne r10, #50
351     74:  -bne  b4
354     78:  mvn   r7, #0
357     7c:  mvn   r8, #254
360     80:  add   r9, r7, r8
363     84:  cmn   r9, #256
366     88:  -movne r10, #60
369     8c:  -bne  b4
372     90:  ldr   r1, [pc, #60]
377         read  addr d4, data 7fffffff
381     94:  mov   r2, #1
384     98:  adds  r3, r1, r2
387     9c:  -bvc  b4
390    a0:  ldr   r0, [pc, #48]
395         read  addr d8, data 80000000
399    a4:  cmp   r0, r3
402    a8:  -movne r10, #70
405    ac:  -bne  b4
408    b0:  b     c0
410         jump  from b0 to c0, r0 80000000, r1 7fffffff
417    c0:  ldr   r11, [pc, #8]
422         read  addr d0, data f0000000
426    c4:  mov   r10, #17
429    c8:  str   r10, [r11]
432         write addr f0000000, data 00000011, be f

```

2.4.2

Figure 2 - GTKWave waveform viewer

2.4.3 Program Trace Utility

A utility is provided that traces all function calls made during a Verilog simulation. Here is an example usage;

```

$ cd $AMBER_BASE/hw/sim
$ run ethmac-test
$ ln -s ../../sw/tools/amber-jumps.sh jumps
$ jumps ethmac-test

```

This produces the following output. The left column gives the time of the event. The next column gives the name of the calling function. The next column gives the value of the r0 register. This register holds the first parameter passed in function calls. The next column gives the name of the function called.

```

276031 u main -> ( 00008dec, ) printf u
276104 u printf -> ( 07ffff8c, ) print u
276311 u print -> ( 00000053, ) _outbyte u

```

```
276411 print <- ( 00000053, )
etc.
```

2.5 Hardware Tests

The Amber package contains a set of tests which are used to verify the correct operation of all the instructions, interrupts, the cache and peripherals. The tests are written in assembly. Several of the tests were added when a specific bug was found while debugging the core. To run one of the tests, use `run <test-name>`, e.g.

```
$ cd $AMBER_BASE/hw/sim
$ run barrel_shift
```

Each test generates pass or fail when it completes, e.g.

```
# ++++++
# Passed barrel_shift
# ++++++
```

To run the complete test suite;

```
$ cd $AMBER_BASE/hw/sim
$ run -a
```

Once the run is complete look at the output file `hw-tests.log` in the `$AMBER_BASE/hw/sim/` directory to check the results. All tests should pass.

The following table describes each test. The source files for these tests are in the directory `$AMBER_BASE/hw/tests`.

Table 2 Amber Core Hardware Verification Tests

Name	Description
adc	Tests the adc instruction. Adds 3 32-bit numbers using adc and checks the result.
addr_ex	Tests an address exception interrupt. Sets the pc to 0x3ffffc and executes a nop. The pc then increments to 0x4000000 triggering an address exception.
add	Tests the add instruction. Runs through a set of additions of positive and negative numbers, checking that the results are correct. Also tests that the 's' flag on the instruction correctly sets the condition flags.
barrel_shift_rs	Tests the barrel shift operation with a mov instruction, when the shift amount is a register value. Test that shift of 0 leaves Rm unchanged. Tests that a shift of > 32 sets Rm and carry out to 0.
barrel_shift	Tests the barrel shift operation with a mov instruction when the shift amount is an immediate value. Tests lsl, lsr and ror.
bcc	Tests branch on carry clear.
bic_bug	Test added to catch specific bug with the bic instruction. The following instruction stored the result in r3, instead of r2 tst r2, r0, lsl r3 bicne r2, r2, r0, lsl r3
bl	Test Branch and Link instruction. Checks that the correct return address is stored in the link register (r14).
cache1	Contains a long but simple code sequence. The entire sequence can fit in the cache. This sequence is executed 4 times, so three times it will execute from the cache. Test passes if sequence executes correctly.
cache2	Tests simple interaction between cached data and uncached instruction accesses.

Name	Description
cache3	Tests that the cache can write to and read back multiple times from 2k words in sequence in memory - the size of the cache.
cacheable_area	Tests the cacheable area co-processor function.
cache_flush	Tests the cache flush function. Does a flush in the middle of a sequence of data reads. Checks that all the data reads are correct.
cache_swap_bug	Tests the interaction between a swap instruction and the cache. Runs through a main loop multiple times with different numbers of nop instructions before the swp instruction to test a range of timing interactions between the cache state machine and the swap instruction.
cache_swap	Fills up the cache and then does a swap access to data in the cache. That data should be invalidated. Check by reading it again.
change_mode	Tests teq, tst, cmp and cmn with the p flag set. Starts in supervisor mode, changes to Interrupt mode then Fast Interrupt mode, then supervisor mode again and finally User mode.
change_sbits	Change status bits. Tests movs where the destination register is r15, the pc. Depending on the processor mode and whether the s bit is set or not, some or none of the status bits will change.
ddr31	Word accesses to random addresses in DDR3 memory. The test creates a list of addresses in an area of boot_mem. It then writes to all addresses with data value equal to address. Finally it reads back all locations checking that the read value is correct.
ddr32	Tests byte read and write accesses to DDR3 memory.
ddr33	Test back to back write-read accesses to DDR3 memory.
ethmac_mem	Tests wishbone access to the internal memory in the Ethernet MAC module.
ethmac_reg	Tests wishbone access to registers in the Ethernet MAC module.
ethmac_tx	Tests ethernet MAC frame transmit and receive functions and Ethmac DMA access to hiboot mem. Ethmac is put in loopback mode and a packet is transmitted and received.
firq	Executes 20 FIRQs at random times while executing a small loop of code. The interrupts are triggered using a ransom timer. Test checks the full set of FIRQ registers (r8 to r14) and will only pass if all interrupts are handled correctly.
flow_bug	The core was illegally skipping an instruction after a sequence of 3 conditional not-execute instructions and 1 conditional execute instruction.
flow1	Tests instruction and data flow. Specifically tests that a stm writing to cached memory also writes all data through to main memory.
flow2	Tests that a stream of str instructions writing to cached memory works correctly.
flow3	Tests ldm where the pc is loaded which causes a jump. At the same time the mode is changed. This is repeated with the cache enabled.
hiboot_mem	Tests wishbone read and write access to hi (non-cachable) boot SRAM.
inflate_bug	A load store sequence was found to not execute correctly.
irq	Tests running a simple algorithm to add a bunch of numbers and check that the result is correct. This algorithm runs 80 times. During this, a whole bunch of IRQ interrupts are triggered using the random timer.
ldm_stm_onetwo	Tests ldm and stm of single registers with cache enabled. Tests ldm and stm of 2 registers with cache enabled.
ldm1	Tests the standard form of ldm.
ldm2	Tests ldm where the user mode registers are loaded whilst in a privileged mode.
ldm3	Tests ldm where the status bits are also loaded.
ldm4	Tests the usage of ldm in User Mode where the status bits are loaded. The s bit should be ignored in User Mode.
ldr	Tests ldr and ldrb with all the different addressing modes.
ldr_atr_pc	Tests lrd and str of r15.
mia	Tests the mia (multiply and accumulate) instruction.
mlas_bug	Bug with Multiply Accumulate. The flags were getting set 1 cycle early.
movs_bug	Tests a movs followed by a sequence of ldr and str instructions with different condition fields.
mul	Tests the mul (multiply) instruction.
sbc	Tests the 'subtract with carry' instruction by doing 3 64-bit subtractions.
stm_stream	Generates as dense a stream of writes as possible to check that the memory subsystem can cope

Name	Description
	with this worst case.
stm1	Tests the normal operation of the stm instruction.
stm2	Test jumps into user mode, loads some values into registers r8 - r14, then jumps to FIRQ and saves the user mode registers to memory.
strb	Tests str and strb with different indexing modes.
sub	Tests sub and subs.
swi	Tests the software interrupt – swi.
swp_lock_bug	Bug broke an instruction read immediately after a swp instruction.
swp	Tests swp and swpb.
uart_reg	Tests wishbone read and write access to the Amber UART registers.
uart_rxint	Tests the UART receive interrupt function. Some text is sent from the test_uart to the uart and an interrupt generated.
uart_rx	Tests the UART receive function.
uart_tx	Uses the tb_uart in loopback mode to verify the transmitted data.
undefined_ins	Tests Undefined Instruction Interrupt. Fires a few unsupported floating point unit (FPU) instructions into the core. These cause undefined instruction interrupts when executed.

2.6 C Programs

In addition to the short assembly language tests, some longer programs written in C are included with the Amber system. These can be used to further test and verify the system, or as a basis to develop your own applications.

The source code for these programs is in \$AMBER_BASE/sw.

2.6.1 Serial Boot Loader

This is located in \$AMBER_BASE/sw/boot-loader-serial. It can be run in simulation as follows;

```
$ cd $AMBER_BASE/hw/isim
$ ./run.sh boot-loader-serial
```

The simulation output looks like the following;

```
# Test boot-loader, log file boot-loader.log
# Load boot memory from ../../sw/boot-loader/boot-loader.mem
# Read in 1928 lines
# Amber Boot Loader v20110202130047
# Commands
# l                : Load elf file
# b <address>      : Load binary file to <address>
# d <start address> <num bytes> : Dump mem
# h                : Print help message
# j                : Execute loaded elf, jumping to 0x00080000
# p <address>      : Print ascii mem until first 0
# r <address>      : Read mem
# s                : Core status
# w <address> <value> : Write mem
# r 0 0000000c
# r 1 00001b76
# r 2 00000000
# r 3 00000000
# r 4 deadbeef
# r 5 deadbeef
# r 6 deadbeef
# r 7 deadbeef
# r 8 deadbeef
```

```

# r 9  deadbeef
# r10 deadbeef
# r11 deadbeef
# r12 00000048
# r13 600002f7
# sp  01ffff80
# pc  600002f3
#
# -----
# Amber Core
# User      FIRQ      IRQ      > SVC
# r0      0x00000001
# r1      0x00001c35
# r2      0x00000000
# r3      0x00000000
# r4      0xdeadbeef
# r5      0xdeadbeef
# r6      0xdeadbeef
# r7      0xdeadbeef
# r8      0xdeadbeef  0xdeadbeef
# r9      0xdeadbeef  0xdeadbeef
# r10     0x00000011  0xdeadbeef
# r11     0xf0000000  0xdeadbeef
# r12     0x00000048  0xdeadbeef
# r13     0xdeadbeef  0xdeadbeef  0xdeadbeef  0x01ffffc0
# r14 (lr) 0xdeadbeef  0xdeadbeef  0xdeadbeef  0x20000763
# r15 (pc) 0x00001250
#
# Status Bits: N=0, Z=1, C=1, V=0, IRQ Mask 0, FIRQ Mask 0, Mode = Supervisor
# -----
#
# ++++++
# Passed boot-loader
# ++++++

```

The boot loader is used to download longer applications onto the FPGA development board via the UART port and using Hyper Terminal on a host Windows PC.

2.6.2 Hello World

This is located in `$AMBER_BASE/sw/hello-world`. It can be run in simulation as follows;

```

$ cd $AMBER_BASE/hw/isim
$ ./run.sh hello-world

```

This is a very simple example of a stand alone C program. The `printf` function it uses is contained in `$AMBER_BASE/sw/mini-libc`, so that it can run on an FPGA without access to a real `libc` library file.

2.6.3 Ethmac Boot Loader

This is located in `$AMBER_BASE/sw/boot-loader-ethmac`. This is an 'over the network' boot loader. It supports telnet for command and status, and `tftp` for uploading executable programs (as elf files) to run on the FPGA.

The IP address is hard-coded in `$AMBER_BASE/sw/boot-loader-ethmac/packet.c`, line 56. To change it, edit that file and rebuild the FPGA, creating a new bitfile.

Here's an example usage of the boot-loader;

```

$ telnet 192.168.0.17
Trying 192.168.0.17...
Connected to 192.168.0.17.
Escape character is '^]'.
Amber Processor Boot Loader

```

```
> s
Socket ID      0
Packets received 10
Packets transmitted 9
Packets resent 0
TCP checksum errors 0
Counterparty IP 192.168.0.52
Counterparty Port 55318
Malloc pointer 0x01223600
Malloc count 531
Uptime 21 seconds
>
```

2.7 Linux

A memory file is provided to run a simulation of Linux booting. The main reason for providing this file is to have a long test to further validate the correct operation of the core. This file was created from a modified version of the 2.4.27 kernel with the patch-2.4.27-vrs1.bz2 patch file applied and then some modifications made to source files to support the specific hardware in the Amber 2 FPGA.

The vmlinux.mem memory file contains an embedded ext2 format ramdisk image which contains the hello-world program, but renamed as /sbin/init. The kernel mounts the ramdisk as /dev/root and runs init. This program prints "Hello, World" and writes the test pass value to the simulation control register. To run this simulation;

```
$ cd $AMBER_BASE/hw/isim
$ ./run.sh vmlinux
```

This simulation takes about 6 million ticks to run to completion, or between 5 minutes and an hour of wall time depending on your simulator and PC. The following is the output from this simulation;

```
# Amber Boot Loader v20110117211518
# j 0x2080000
#
# Linux version 2.4.27-vrs1 (conor@server) (gcc version 4.5.1 (Sourcery G++ Lite 2010.09-50) ) #354 Tue Feb 1 17:56:00 GMT 2011
# CPU: Amber 2 revision 0
# Machine: Amber-FPGA-System
# On node 0 totalpages: 1024
# zone(0): 1024 pages.
# zone(1): 0 pages.
# zone(2): 0 pages.
# Kernel command line: console=ttyAM0 mem=32M root=/dev/ram
# Calibrating delay loop... 19.91 BogoMIPS
# Memory: 32MB = 32MB total
# Memory: 31136KB available (493K code, 195K data, 32K init)
# Dentry cache hash table entries: 4096 (order: 0, 32768 bytes)
# Inode cache hash table entries: 4096 (order: 0, 32768 bytes)
# Mount cache hash table entries: 4096 (order: 0, 32768 bytes)
# Buffer cache hash table entries: 8192 (order: 0, 32768 bytes)
# Page-cache hash table entries: 8192 (order: 0, 32768 bytes)
# POSIX conformance testing by UNIFIX
# Linux NET4.0 for Linux 2.4
# Based upon Swansea University Computer Society NET3.039
# Starting kswapd
# ttyAM0 at MMIO 0x16000000 (irq = 1) is a WSBN
# pty: 256 Unix98 ptys configured
# RAMDISK driver initialized: 16 RAM disks of 208K size 1024 blocksize
# NetWinder Floating Point Emulator V0.97 (double precision)
# RAMDISK: ext2 filesystem found at block 8388608
# RAMDISK: Loading 200 blocks [1 disk] into ram disk... done.
# Freeing initrd memory: 200K
```



```
# VFS: Mounted root (ext2 filesystem) readonly.
# Freeing init memory: 32K
# Hello, World!
#
# -----
# Amber Core
#   > User      FIRQ      IRQ      SVC
# r0      0x00000010
# r1      0x0080ee00
# r2      0x00000000
# r3      0x00000000
# r4      0x00000000
# r5      0x00000000
# r6      0x00000000
# r7      0x00000000
# r8      0x00000000 0xdeadbeef
# r9      0x00000000 0xdeadbeef
# r10     0x00000011 0xdeadbeef
# r11     0xf0000000 0xdeadbeef
# r12     0x00000000 0xdeadbeef
# r13     0x019fff40 0xdeadbeef 0x0210bca4 0x02161fe8
# r14 (lr) 0x00000000 0xdeadbeef 0x220a437f 0x0080e428
# r15 (pc) 0x0080e800
#
# Status Bits: N=0, Z=1, C=1, V=0, IRQ Mask 0, FIRQ Mask 0, Mode = User
# -----
#
# ++++++
# Passed vmlinux
# ++++++
```

The program trace utility can be used to trace the Linux execution, as follows;

```
$ cd $AMBER_BASE/hw/sim
$ ln -s ../../sw/tools/amber-jumps.sh jumps
$ jumps vmlinux
```

3 FPGA Synthesis

A makefile is provided that performs synthesis of the system to a Xilinx Spartan-6 FPGA. To use this makefile you must have Xilinx ISE installed. I have tested it with ISE v14.5. The makefile is quite flexible. To see all its options, type;

```
$ cd $AMBER_BASE/hw/fpga/bin
$ make help
```

To use the script to perform a complete synthesis run from start to finish and generate a bitfile;

```
$ cd $AMBER_BASE/hw/fpga/bin
$ chmod +x *.sh
$ make new
```

The script performs the following steps

1. Compiles the boot loader program in \$AMBER_BASE/sw/boot-loader, to ensure the latest version goes into the boot_mem ram blocks.
2. Runs xst to synthesize the top-level Verilog file \$AMBER_BASE/hw/vlog/system/system.v and everything inside it.
3. Runs ngbbuild to create the initial FPGA netlist.
4. Runs map to do placement.
5. Runs par to do routing.
6. Runs bitgen to create an FPGA bitfile in the bitfile directory.
7. Runs trce to do timing analysis on the finished FPGA.

The Spartan-6 FPGA target device is the default. To compile for the Virtex-6 FPGA, set VIRTEX6=1 on the command line, e.g.

```
$ cd $AMBER_BASE/hw/fpga/bin
$ make new VIRTEX6=1
```

The Amber 23 core is the default. To synthesize the Amber 25 core instead, set A25=1 on the command line, e.g.

```
$ cd $AMBER_BASE/hw/fpga/bin
$ make new A25=1
```

If the par step fails (timing or area constrains not met), you can rerun map and par with a different seed. Simply call the makefile again without the new switch. The makefile will automatically increment the seed, e.g.

```
$ cd $AMBER_BASE/hw/fpga/bin
```

```
$ make
```

The system clock speed is configured within the FPGA makefile, `$AMBER_BASE/hw/fpga/bin/Makefile`. To change it, change the value of `AMBER_CLK_DIVIDER` in that file. The system clock frequency is equal to the PLL's VCO clock frequency divided by `AMBER_CLK_DIVIDER`. By default it is set to 40MHz for Spartan-6 and 80MHz for Virtex-6.

4 Using Boot-Loader

If you have a development board with a UART connection to a PC you can use boot-loader to download and run applications on the board. I have tested this with the Xilinx SP605 development board. It provides a UART connection via a USB port on the board.

4.1 Install and configure Minicom

The following commands installs the lusb and minicom utilities;

```
$ sudo yum install usbutils
$ sudo yum install minicom
```

Connect the SP605 serial port USB to the PC and check that the port is visible;

```
ls -l /dev/ttyUSB0
crw-rw---- 1 root dialout 188, 0 May  4 11:02 /dev/ttyUSB0

$ lsusb
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
Bus 002 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
Bus 003 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 004 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 005 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 006 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 007 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 008 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub
Bus 001 Device 002: ID 05e3:0608 Genesys Logic, Inc. USB-2.0 4-Port HUB
Bus 005 Device 002: ID 046e:55a5 Behavior Tech. Computer Corp.
Bus 005 Device 003: ID 04f3:0212 Elan Microelectronics Corp. Laser Mouse
Bus 002 Device 013: ID 03fd:0008 Xilinx, Inc.
Bus 008 Device 006: ID 10c4:ea60 Cygnal Integrated Products, Inc. CP210x UART Bridge /
myAVR mySmartUSB light
```

Configure minicom

```
sudo minicom -s

+-----+
| A -   Serial Device       : /dev/ttyUSB0
| B - Lockfile Location    : /var/lock
| C -   Callin Program     :
| D -   Callout Program    :
| E -   Bps/Par/Bits       : 921600 8N1
| F - Hardware Flow Control : Yes
| G - Software Flow Control : No
|
|   Change which setting?
+-----+
```

Save setup as dfl. Then to run minicom,

```
> sudo minicom
```

4.2 Configure the FPGA

Load the bitfile into the FPGA on the development board. This can be done using Xilinx iMPACT. Once the FPGA is configured the boot loader will print some messages via the UART interface onto the minicom screen, as follows;

5 License

All source code provided in the Amber package is release under the following license terms;

```
Copyright (C) 2010 Authors and OPENCORES.ORG

This source file may be used and distributed without
restriction provided that this copyright statement is not
removed from the file and that any derivative work contains
the original copyright notice and the associated disclaimer.

This source file is free software; you can redistribute it
and/or modify it under the terms of the GNU Lesser General
Public License as published by the Free Software Foundation;
either version 2.1 of the License, or (at your option) any
later version.

This source is distributed in the hope that it will be
useful, but WITHOUT ANY WARRANTY; without even the implied
warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR
PURPOSE. See the GNU Lesser General Public License for more
details.

You should have received a copy of the GNU Lesser General
Public License along with this source; if not, download it
from http://www.opencores.org/lgpl.shtml

Author(s):
- Conor Santifort, csantifort.amber@gmail.com
```